

SIMATIC S7, F-programming tool, STEP 7 Safety Advanced V14 SP1; Upgrade V11..V13-> V14 SP1 or V11..V13 combo-> V14 SP1 combo; for parallel use of STEP 7 Safety Advanced V11..V13 und STEP 7 Safety Adv.V14 SP1; Engineering SW; Upgrade license for 1 user Software and documentation on DVD; license key on USB stick; Class A, 2 languages (de, en); executable with TIA-Portal V14 SP1 from STEP 7 Professional V14 SP1; For configuration of SIMATIC S7-1200F/1500F, SIMATIC S7-1500F SW Controller, SIMATIC S7-300F/400F/WINAC F;

## Operating systems

Runs under operating system	
• Windows 9x	No
• Windows ME	No
• Windows NT 4.0	No
• Windows 2000	No
• Windows XP	No
• Windows 7	Yes
• Windows 10	Yes

last modified: 08/13/2018